



接入L1,L2,L3这三根线,  
并送电

Connect the three  
lines L1, L2, and L3  
and supply power.

红色指示灯亮起，打开急停开关

The red indicator light illuminates;  
activate the emergency stop switch.



按下正转按钮，机器开始运行

Press the forward button and the machine will start running.



如果机器撕碎过程中卡住了，  
关闭急停开关

然后再重新开启急停开关

再按下反转按钮

If the machine jams during  
shredding, turn off the emergency  
stop switch, then turn it back on,  
and then press the reverse button.





图中圈出的五处位置  
定期加注黄油

The five circled  
locations in the picture  
should be greased  
regularly.



(黄油润滑脂轴承齿轮轨道)  
(Grease-lubricated bearings,  
gears, and rails)